

SECTION 8.

MAINTENANCE

8.1 DISASSEMBLY PROCEDURES

Perform only the steps necessary for service required.

8.1.1 KG106 TRANSCEIVER UNIT

(See Figure 8-1)

Table 8-1. KG106

UNIT	STEP	PROCEDURE
RX UNIT	1	Remove two cap bolts (28) and bolt spacers (39) from bottom cover (26).
	2	Remove two cap bolts (27) from bottom cover (26).
	3	Remove top and bottom covers (26) from chassis (25).
	4	Remove ten screws (32) from RX unit chassis (13).
	5	Remove RX unit cover (13) from RX unit chassis (12).
	6	Pry off RX VCO unit cover (41) from RX VCO PCB (20).
	7	Remove four studs (21) and one screw (22) from RX VCO PCB (20).
	8	Unplug RX VCO PCB (20) from RX main PCB (11).
	9	Remove six screws (33) from RX unit chassis (12).
	10	Remove RX unit chassis (12) from main chassis (25).
	11	Remove three screws (32) from RX unit chassis (12).
	12	Remove twelve screws (34) from RX main PCB (11).
	13	Remove RX main PCB (11) from RX unit chassis (12).
TX UNIT	1	Remove eight screws (32) from TX unit cover (17).
	2	Remove TX unit cover (17) from TX unit chassis (16).
	3	Remove four studs (21) from TX VCO PCB (23).
	4	Unplug TX VCO PCB (23) from TX main PCB (15).
	5	Remove eight screws (33) from TX unit chassis (16).
	6	Remove TX unit chassis (16) from main chassis (25)..
	7	Remove three screws (32) from TX unit chassis (16).
	8	Remove eight screws (34) from TX main PCB (15).
	9	Remove TX main PCB (15) from TX unit chassis (16).

Table 8-1. Cont'd

UNIT	STEP	PROCEDURE
TERMINAL UNIT	1	Remove D-sub cover (47) from terminal PCB (24).
	2	Remove two D-sub studs (46) from terminal PCB (24).
	3	Remove two screws (30) and one screw (3) from terminal PCB (24).
	4	Remove terminal PCB (24) from main chassis (25).
PA UNIT	1	Remove four screws (31) from main chassis (25).
	2	Remove PA unit heat sink (10) from main chassis (25).
	3	Remove seven screws (9) from PA cover (4).
	4	Remove PA cover (4) from PA unit heat sink (10).
	5	Remove seven PA studs (1) from PA PCB (8).
	6	Remove four screws (2) and one screw (3) from PA PCB (8).
	7	Remove PA PCB (8) from PA unit heat sink (10).
DUPLEXER	1	Remove four screws (29) from duplexer.
	2	Remove duplexer from main chassis (25).
	3	To reassemble reverse the steps above.

8.1.2 KD-357M MICROPHONE

(See Figure 8-2)

Table 8-2. KD-357M Microphone

UNIT	STEP	PROCEDURE
MICROPHONE	1	Remove three screws (7) from rear case (9).
	2	Remove one screw (24) from the inside of the rear case (9).
	3	Remove switch button (10) from rear case (9).
	4	Remove [PTT] button (1) and gasket (3) from rear case (9).
	5	Lift out monitor switch (21) and PTT switch (22) to remove from plastic housing (17).
	6	Lift out plastic housing (17) and mic. element (18) from front case (5).
	7	Remove foam pad (19) from front case (5).
	8	To reassemble reverse the steps above.

REF. NO.	PART NAME	PART NO.	QTY.	VENDOR
1	PTT BUTTON	14-11-365-08	1	KCS
2	GRILLE/MESH OR PLAS.	14-14-382-01	1	KCS
3	PTT BUTTON GASKET	-	1	-
4	PUSHBUTTON HOUSING	14-11-442-00	1	KCS
5	FRONT CASE	14-60-512-04	1	KCS
6	COILED CABLE/BUSHING	14-43-366-03	1	KCS
7	SELF TAP SCREW 3x11	99-40-0203-1200	3	KCS
8	HANG-UP BUTTON	14-11-415-00	1	KCS
9	REAR CASE	14-60-513-04	1	KCS
10	MONITOR SWITCH BUTTON	14-11-366-00	1	KCS
11	MONITOR DECAL	14-15-242-02	1	KCS
12	HOUSING GASKET	-	1	-
13	CALL/RESET SWITCH BUTTONS	14-17-119-00	2	KCS
14	CALL/RESET DECAL	14-15-221-05	1	KCS
15	ANGLE CONN-(ASSY)	14-7PL	1	KCS
16	PLASTIC HOUSING	-	1	-
17	MIC. ELEMENT	-	1	-
18	FOAM PAD	-	1	-
19	CALL/RESET SWITCH	-	2	-
20	MONITOR SWITCH	-	1	-
21	PTT SWITCH	-	1	-
22	CIRCUIT BOARD	-	1	-
23	PAN SCREW 3 x 5.5	-	1	-
24	SOLDER LUG	-	1	-
25	MONITOR SWITCH GASKET	-	1	-

NOTE:

- * ITEMS (#6) AND (#15)
ARE SUPPLIED ASSEMBLED
- * KCS = KYODO CUSTOMER SERVICE

MIC. HANG-UP CLIP

REF. NO.	PART NAME	PART NO.	QTY.
A	HANGER	14-11-64-01	1
B	SCREW	99-40-0204-1214	3
C	WASHER	99-47-1104-23	3
D	VINYL BAG	14-56-10-00	1

Figure 8-2. Exploded View of KD-357M Microphone

8.1.3 CONTROL UNIT


(See Figure 8-3)

NOTE:

Use extreme caution in handling flexible circuits.

Table 8-3. Control Unit

UNIT	STEP	PROCEDURE
CONTROL UNIT	1	Remove two screws (8) to detach control unit (9) from control cable assembly.
	2	Remove volume and squelch knobs (7) using 1.27 mm Allen wrench.
	3	Remove channel knob (5) using 1.5 mm Allen wrench.
	4	Pry off power button (3) using thin screwdriver on bottom edge.
	5	Unscrew ring for microphone (1) and spring washer (2).
	6	Unplug 12-pin socket (25).
	7	Remove two screws (18) from control unit PCB "E" (16).
	8	Remove four screws (19) from control unit PCB "E" (16).
	9	Remove two screws (20) from power switch (21).
	10	Remove two studs (17) from control unit PCB "C" (29).
	11	Remove one screw (18) from control unit PCB "A" (13).
	12	Remove two studs (14) from speaker clamp "A" (13) and remove clamp.
	13	Remove two studs (14) from speaker clamps "B" (15) and remove clamps.
	14	Lift off spring for speaker (12) and remove PCBs from control panel (9).
	15	To reassemble, reverse the steps above.



REF. NO.	PART NAME	PART NO.	QTY.
1	MIC SPRING WASHER	00-16-19	1
2	RING FOR MIC	714-SM	1
3	POWER BUTTON	3A11-0231	1
4	TONE BUTTONS	4A11-1043	2
5	CHANNEL SELECTOR KNOB	4A11-1046	1
6	LED WINDOW	4A10-0975	1
7	VOL/SOL KNOB	4A11-1047	2
8	OVAL SCREW	OV-4 x 5	2
9	CONTROL PANEL	2A10-0080-11E	1
10	SPEAKER	KS-105	1
11	SPEAKER RUBBER	4A10-1116	1
12	SPRING FOR SPEAKER	4A10-1030	1
13	SP CLAMP "A"	4A10-1028	1
14	STUD FOR CONT L=11.2	4A10-1034-A	4
15	SP CLAMP "B"	4A10-1029	2
16	CONT UNIT PCB "E"	05CTC187	1
17	STUD FOR CONT L=14.8	4A10-1034-B	2
18	SEMS SCREW L/W	SE-2.6 x6	3
19	SEMS SCREW L/W	SE-2.6 x10	4
20	BINDER SCREW	BD-2 x 5	2
21	POWER SWITCH	SUT11 018	1
22	MIC CONNECTOR	214-75M	1
23	NUT	NAT-2.6PAI	1
24	PAN SCREW	PN-2.6 x 8	1
25	12-PIN SOCKET	IL-S-12P-S212	1
26	SPRING WASHER	SW-2.6PAI	1
27	CONT UNIT PCB "D"	05CTC188	1
28	NET FOR SPEAKER	4A11-1036	1
29	CONT UNIT PCB "C"	05CTC188	1
30	CONT UNIT PCB "B"	05CTC188	1
31	CONT UNIT PCB "A"	05CTC188	1
32	SPACER FOR PCB	4A10-1040	4
33	INSULATOR FOR CONT	4A10-1086	1

Figure 8-3. Exploded View of Control Unit




Figure 8-4. DTMF Handset Schematic

- NOTE:
1. ALL CONNECTIONS IN CIRCUITS ARE TO GND UNLESS OTHERWISE NOTED.
 2. ACTUATOR AND CONTACTS ARE SHOWN FOR REFERENCE ONLY.
 3. 12 CIRCUIT AND 12 LINE CONTACTS SHOWN BY JUMPER WHEN S3 IS NOT INSTALLED.




Figure 8-5. Handset Base Unit Schematic

1. ALL RESISTORS IN OHMS AND 1/4W 5% CARBON FILM
 2. ALL CAPACITORS IN UF UNLESS OTHERWISE NOTED
 3. PCB SCREEN MAY BE LAYERED W/O 300 SERIES NUMBERS
 4. AMP1 REPLACED BY 470 OF 50V MONOLITHIC CERAMIC
- Capacitor #1 model: 550 mF




Figure 8-6. KG106 Terminal Unit Schematic

8.2 PARTS LIST

MODEL:KG106 UHF

UNIT:RECEIVER

REF.NO.	PART NAME	PART NO.	REF.NO.	PART NAME	PART NO.
BPF101,2	BPF-3	RFC450N-3,33	IC104	IC	UPB571C
C101,02A	ELECTROLYTIC CAP.	KMA 16V/47UF	IC105	IC	TCS027P
C102B-044	TANTALUM CAP.	DN 35V/1UF	IC106	IC	TCS036P
C105,16,55B	ELECTROLYTIC CAP.	KMA 16V/22UF	IC107	IC	TK10420
C106,07	CERAMIC CAP.	B 1000PF	IC108,10	IC	NJM4558D
C108,22,92A	CERAMIC CAP.	CH 3PF	IC109	IC	CX7932
C109,10	MONOLITHIC CERAMIC CAP.	RPE121C 1000PF	IC111	IC	NJM2073
C111,90	FILM CAP.	A7Z 0.022UF	IC112	IC	78M05
C112	TANTALUM CAP.	DN 10V/47UF	IC113	IC	AN78N08
C113A	TANTALUM CAP.	SST 35V/0.1UF	IC114	IC	7808
C113B	TANTALUM CAP.	DN 35V/0.1UF	IC115	IC	TA7303
C114,83,84	MONOLITHIC FILM CAP.	B32529-104K	JP101,R122A	CARBON RES.	1/6W(P) 0
C115,52,53	TANTALUM CAP.	DN 16V/2.2UF	JP102	JUMPER PLUG	DSP02-002-431G
C117-20	CERAMIC CAP.	B 470PF	JP102S	JUMPER SOCKET	DSP01-002-430G
C121,43	TANTALUM CAP.	DN 35V/1UF	L101,02	LEAD CHOKE	15M (LN-0009)
C123	CERAMIC CAP.	CH 7PF	L104	COIL	4A-S235
C124	CERAMIC CAP.	U1 470PF	L105	COIL	#1054
C125,30	CERAMIC CAP.	RH 39PF	L106	MICRO INDUCTOR	LA03NA-10UH
C126,34	CERAMIC CAP.	RH 56PF	L107A	MICRO INDUCTOR	LA03NA-100UH
C127,32,35	CERAMIC CAP.	B 2200PF	L107B,09	COIL	M2 680UH
C128,29	CERAMIC CAP.	CH 6PF	L108	COIL	G02 10MH
C131,36,92B	CERAMIC CAP.	B 1000PF	Q101	TRANSISTOR	2SC3358
C133	CERAMIC CAP.	RH 5PF	Q102	FET	2SK152
C137	CERAMIC CAP.	CH 33PF	Q103	TRANSISTOR	2SC2669Y
C138	CERAMIC CAP.	CH 68PF	Q104,08	TRANSISTOR	2SC2458LY
C139-41	MONOLITHIC CERAMIC CAP.	RPE121C 0.1UF	Q105,10,12	TRANSISTOR	RN2202
C142	CERAMIC CAP.	CH 150PF	Q106,07	TRANSISTOR	2SA1048LY
C144	CERAMIC CAP.	SL 220PF	Q109	TRANSISTOR	2SA950Y
C145,46,48,49	POLYPROPYLENE CAP.	UPZ 470PF	Q111	FET	2SK184
C147	CERAMIC CAP.	CH 82PF	R101-07,08B	CARBON RES.	1/6W(F) 10K
C148,75	ELECTROLIC CAP.	KMA 50V/0.47UF	R108A,36,38A	CARBON RES.	1/6W(F) 47K
C150	CERAMIC CAP.	CH 10PF	R109,77	CARBON RES.	1/6W(F) 1K
C151,64,65,69	FILM CAP.	A7Z 4700PF	R110-12,18	CARBON RES.	1/6W(F) 10K
C154	ELETROLIC CAP.	KMA 50V/1UF	R113,34	CARBON RES.	1/6W(F) 220
C155A	ELETROLIC CAP.	BP 50V/0.47UF	R114,17,30	CARBON RES.	1/6W(F) 820
C156	FILM CAP.	A7Z 6800PF	R115,27	CARBON RES.	1/6W(F) 1.2K
C157	FILM CAP.	A7Z 1200PF	R116,57,60	CARBON RES.	1/6W(F) 3.3K
C159	ELECTROLYTIC CAP.	KMA 50V/0.1UF	R119,25	CARBON RES.	1/6W(F) 2.7K
C160	ELECTROLYTIC CAP.	KMA 25V/4.7UF	R120,40,49,54,63	CARBON RES.	1/6W(F) 15K
C161,89A	ELECTROLYTIC CAP.	KMA 50V/2.2UF	R121,26,51	CARBON RES.	1/6W(F) 100
C162,63	POLYPROPYLENE CAP.	UPZ 220PF	R123	CARBON RES.	1/6W(F) 56
C166,71-74	FILM CAP.	A7Z 1000PF	R124,28	CARBON RES.	1/6W(F) 150
C167,68	FILM CAP.	A7Z 0.015UF	R129,32,42	CARBON RES.	1/6W(F) 10K
C170	FILM CAP.	A7Z 8200PF	R131	CARBON RES.	1/6W(F) 470
C176	TANTALUM CAP.	DN 35V/0.47UF	R133,52,80,84	CARBON RES.	1/6W(F) 22K
C177,78,91	FILM CAP.	A7Z 0.01UF	R135,39,68,88	CARBON RES.	1/6W(F) 1.5K
C179	ELECTROLYTIC CAP.	BP 16V/10UF	R137,38B	CARBON RES.	1/6W(F) 2.2K
C180,81,82A	ELECTROLYTIC CAP.	KMA 16V/100UF	R141,55,56	CARBON RES.	1/6W(F) 47K
C185-87A	TANTALUM CAP.	DN 35V/1UF	R143,48,81,82	CARBON RES.	1/6W(F) 100K
C187B,89B	FILM CAP.	A7Z 1000PF	R144,46	CARBON RES.	1/6W(F) 33K
C188	ELECTROLYTIC CAP.	SR 25V/1000UF	R145	CARBON RES.	1/6W(F) 39K
CD101	DISCRIMINATOR	CDB455C7	R147,64,75	CARBON RES.	1/6W(F) 10K
CF101	CERAMIC FILTER	CFG455D	R150	CARBON RES.	1/6W(F) 1.8K
CN101P	8-PIN PLUG	8263-0812-000	R153,70	CARBON RES.	1/6W(F) 18K
CN102P	12-PIN PLUG	8263-1212-000	R158,59	CARBON RES.	1/6W(F) 240K
CN103S	7-PIN SOCKET	3024-07CH	R161,62	CARBON RES.	1/6W(F) 47K
CN104S	2-PIN SOCKET	3024-02CH	R165,66	CARBON RES.	1/6W(F) 12K
CN107S	10-PIN SOCKET	3024-10CH	R167	CARBON RES.	1/6W(F) 180K
CN108P	3-PIN PLUG	8263-0312-000	R169,87	CARBON RES.	1/6W(F) 4.7K
CNS5,6S	COAXIAL CONNECTOR	SM551	R171,172,79	CARBON RES.	1/6W(F) 220K
CN5P	COAXIAL CONNECTOR	106-RX-1.5D	R173	CARBON RES.	1/6W(F) 68K
D101-05,07	DIODE	ISS177	R174	CARBON RES.	1/6W(F) 620K
D106	LED	ISS237	R176,83,85	CARBON RES.	1/6W(F) 10K
D108,11	DIODE	NAL-8CS	R178	CARBON RES.	1/6W(F) 30K
D109	DIODE	ISS227	R186	CARBON RES.	1/6W(F) 8.2K
D110,12-15	DIODE	ISS177	RA101	RESISTOR ARRAY	RGLN8X-103K
D116,17	DIODE	ISS237	T101,03	COIL	#1053
DA101	DIODE- ARRAY	NAL-8CS	T102	COIL	#1058
DBM101	BALANCED MIXER	M8	TCX01	TCXO	GFS-210W
FVR101-03	SEMI FIXED RES.	CT-6P 10K	TH101	THERMISTOR	360-D5
IC101	EPROM	MBM2764	X101	XTAL	21.145MHz
IC102	IC	MC14504BP	XF101	XTAL FILTER	21P20C
IC103	IC	MC145146P	XF102	XTAL FILTER	21P18A

REF.NO.	PART NAME	PART NO.	REF.NO.	PART NAME	PART NO.	
	IC SOCKET	110-99-628	L304	LEAD CHOKE	10M(LN-0018)	
	COAXIAL WIRE	06-0.8D	L305	COIL	4A-S165	
	SHIELD WIRE	EMR-IS-MST 28cm	L306,07	COIL	4A-S160	
	PCB	06MPR318	L310,11	VARIABLE COIL	12VXA 68MH	
	RX UNIT CHASSIS	2A10-0105	Q301	TRANSISTOR	2SC2644	
	RX UNIT COVER	3A10-0320	Q302	TRANSISTOR	2SC2131	
	BIND SCREW	BD-2.6 x 5	Q303	TRANSISTOR	2SB1019Y	
	OVAL SCREW	OV-2.6 x 8	Q304,05	TRANSISTOR	RN2202	
	NUT	M2.6	Q306	TRANSISTOR	RN1202	
	SPRING WASHER	M2.6	R301-7,9,11	CARBON RES.	I/6W(F) 10K	
MODEL:KG106 UHF		UNIT:TX MAIN UNIT		R308,42	CARBON RES.	
REF.NO.	PART NAME	PART NO.	R310,33	CARBON RES.	I/6W(F) 47K	
C310,40,43,44	TANTALUM CAP.	DN 35V/1UF	R312-14	CARBON RES.	I/6W(F) 15K	
C311,61	TANTALUM CAP.	DN 10V/10UF	R315,20	CARBON RES.	I/6W(F) 10K	
C312,18,38	ELECTROLYTIC CAP.	KMA 16V/47UF	R316	CARBON RES.	I/6W(F) 3.3K	
C313,14,41	CERAMIC CAP.	B 1000PF	R317,37	CARBON RES.	I/6W(F) 820	
C315	CERAMIC CAP.	CH 2PF	R318,49	CARBON RES.	I/6W(F) 1.2K	
C316,17	MONOLITHIC CERAMIC CAP.	RPEI21C 1000PF	R319	CARBON RES.	I/6W(F) 430	
C319A	TANTALUM CAP.	DN 10V/47UF	R321	CARBON RES.	I/6W(F) 10	
C319B	FILM CAP.	A7Z 0.022UF	R322,40A,52	CARBON RES.	I/6W(F) 680	
C320	TANTALUM CAP.	DN 35V/0.1UF	R323	CARBON RES.	I/6W(F) 15	
C321	TANTALUM CAP.	SST 35V/0.1UF	R324,51	CARBON RES.	I/6W(F) 150	
C322	MONOLITHIC FILM CAP.	B32529-104K	R325	CARBON RES.	I/6W(F) 47	
C323	TANTALUM CAP.	DN 16V/2.2UF	R326	CARBON RES.	I/6W(F) 2.7K	
C324,35	CERAMIC CAP.	SL 33PF	R327	CARBON RES.	I/6W(F) 22	
C325,34,36	CERAMIC CAP.	CH 5PF	R328,45A	CARBON RES.	I/6W(F) 1K	
C326-29,32,33	CERAMIC CAP.	B 470P	R329A,30	CARBON RES.	I/6W(F) 3.3	
C330	CERAMIC CAP.	SL 9PF	R329B	CARBON RES.	I/6W(F) 390	
C331	CERAMIC CAP.	CH 9PF	R331	CARBON RES.	I/6W(F) 270	
C337,62	TANTALUM CAP.	DN 10V/4.7UF	R332	CARBON RES.	I/6W(F) 470	
C339	FILM CAP.	A7Z 0.01UF	R334	CARBON RES.	I/6W(F) 39K	
C342	ELECTROLYTIC CAP.	KMA 16V/100UF	R335	CARBON RES.	I/6W(F) 3.9K	
C345	ELECTROLYTIC CAP.	KMA 25V/100UF	R336,45B	CARBON RES.	I/6W(F) 10K	
C346-48	CERAMIC CAP.	B 1000PF	R338	CARBON RES.	I/6W(F) 2.2K	
C349	FILM CAP.	A7Z 0.068UF	R339,46	CARBON RES.	I/6W(F) 1.5K	
C350	FILM CAP.	A7Z 0.1UF	R340B	CARBON RES.	I/6W(F) 27K	
C351	FILM CAP.	A7Z 0.047UF	R341	CARBON RES.	I/6W(F) 6.8K	
C352,55	TANTALUM CAP.	DN 35V/0.47UF	R343	METAL RES.	RNK2E 33K	
C353	CERAMIC CAP.	B 100PF	R344	METAL RES.	RNK2E 39K	
C354	ELECTROLYTIC CAP.	KMA 16V/10UF	R347	CARBON RES.	I/6W(F) 33K	
C356	FILM CAP.	A7Z 0.015UF	R348	CARBON RES.	I/6W(F) 4.7K	
C357	CERAMIC CAP.	SL 150PF	R350	CARBON RES.	I/6W(F) 150K	
C358-60,63	TANTALUM CAP.	DN 35V/0.47UF	RA301	DIODE ARRAY	RGLN8X-103K	
C364,66,68	CERAMIC CAP.	B 1000PF	TH301	THERMISTOR	50D-5	
C365	TANTALUM CAP.	DN 35V/0.22UF		PCB	06MPT21Z	
C367	CERAMIC CAP.	CH 10PF		IC SOCKET	110-99-628	
CN301P	8-PIN PLUG	8263-0812-000		TX UNIT CHASSIS	2A10-0104	
CN303P	7-PIN PLUG	8263-0712-000		TX UNIT COVER	3A10-0321	
CN304P	3-PIN PLUG	8263-0312-000		COAXIAL WIRE	EMR-15-MST 22cm	
CN304S	3-PIN ASSY	06-304S		BIND SCREW	BD-2.6 x 5	
CN305S	7-PIN SOCKET	3024-07CH		OVAL SCREW	OV-2.6 x 8	
CN306S	2-PIN SOCKET	3024-02CH		NUT	M2.6	
				SPRING WASHER	M2.6	
CN6P	COAXIAL CONNECTOR	106-TCH-1.5D	MODEL:KG106 UHF		UNIT:RX VCO	
CN7P	COAXIAL CONNECTOR	106-YNG-1.5D	REF.NO.	PART NAME	PART NO.	
D301-06	DIODE	ISS177	C201	FILM CAP.	A7Z 0.015UF	
D307	DIODE	ISS227	C202,11,12	CERAMIC CAP.	B 470PF	
D308-10	DIODE	ISS177	C203	CERAMIC CAP.	B 220PF	
D311	LED	TLS164	C204	WEDGE CAP.	SUW35A 1000PF	
D312,13	DIODE	ISS177	C205A,08	CHIP CAP.		
D314,15	DIODE	ISS237	C206	CHIP CAP.	GR40 RH 11PF	
DA301	DIODE ARRAY	NAL-8CS	C207	CHIP CAP.	GR40 RH 4PF	
FVR301	SEMI FIXED RES.	CT-6P 10K	C209	CHIP CAP.	GR40 RH 18PF	
FVR302	SEMI FIXED RES.	CT-6P 1K	C210	CERAMIC CAP.	RH 3PF	
FVR303	SEMI FIXED RES.	CT-6P 47K	C213A	CERAMIC CAP.	RH 15PF	
FVR304	SEMI FIXED RES.	CT-6P 470	C214-16,23,27	CERAMIC CAP.	B 470PF	
IC301	IC	UPD2764D	C217,21,22	TANTALUM CAP.	DN 10V/4.7UF	
IC302	IC	MC14504BP	C218	TANTALUM CAP.	DN 35V/1UF	
IC303	IC	MC145146P	C219,20	ELECTROLYTIC CAP.	KMA 16V/47UF	
IC304	IC	UPB571C	C224	CERAMIC CAP.	B 1000PF	
IC305	IC	TC5027BP	C225	TANTALUM CAP.	DN 10V/47UF	
IC306	IC	78M05	C226	MONOLITHIC CERAMIC CAP.	PEI21C 0.022UF	
IC307	IC	78M08	CN103P	7-PIN PLUG	SB-07P-HVQ-B	
IC308	IC	M5236L	CN104P	2-PIN PLUG	SB-02P-HVQ-B	
IC309	IC	NJM4556	D201	VARICAP DIODE	IT-32	
IC310	IC	MS1304L				
L301-03,08,09	LEAD CHOKE	15M(LN-0009)				

REF.NO.	PART NAME	PART NO.	REF.NO.	PART NAME	PART NO.
D202	DIODE	ISS27	Q404	TRANSISTOR	RN2202
D203-05,07	DIODE	ISS177	Q406	TRANSISTOR	2SC3623A
D206	ZENER DIODE	05ZS.6Y	Q407	TRANSISTOR	2SC2458LY
IC201	IC	UPC1651	R401	CARBON RES.	1/6W(F) 15K
L201	MICRO INDUCTOR	LA03NA 1UH	R402,09,16	CARBON RES.	1/6W(F) 1K
L202	CHOKE COIL	4A-S212	R403	CARBON RES.	1/6W(F) 5.6K
L203	MICRO INDUCTOR	LA03NA 0.47UH	R404	CARBON RES.	1/6W(F) 390
L204	COIL	4A-S341	R405,06,15	CARBON RES.	1/6W(F) 4.7K
L205	COIL	4A-S166	R407	CARBON RES.	1/6W(F) 330
L206	MICRO INDUCTOR	LA03NA 10UH	R408	CARBON RES.	1/6W(F) 2.7K
Q201	FET	SST310	R410	CARBON RES.	1/6W(F) 47
Q202	TRANSISTOR	2SC2753Y	R411,18	CARBON RES.	1/6W(F) 10
Q203,05	TRANSISTOR	2SA1048LY	R412-14	CARBON RES.	1/6W(F) 10K
Q204,06	TRANSISTOR	RN2202	R417	CARBON RES.	1/6W(F) 270
Q207	TRANSISTOR	2SC3623A	TH401	THERMISTOR	TD5-210DH
Q208	TRANSISTOR	2SC2458LY	VC401	TRIMMER	DTM 20PF
R201	CARBON RES.	1/6W(F) 330		VCO STUD	4A10-1267
R202	CARBON RES.	1/6W(F) 220		PCB MAT	4A10-1274
R203	CARBON RES.	1/6W(F) 2.7K		PCB	06VCUDT216
R204,10	CARBON RES.	1/6W(F) 1K		VCO UNIT CASE	4A10-1095
R205	CARBON RES.	1/6W(F) 68			
R206,13	CARBON RES.	1/6W(F) 10			
R207,08	CARBON RES.	1/6W(F) 10K			
R209	CARBON RES.	1/6W(F) 4.7K			
R211	CARBON RES.	1/6W(F) 15K			
R212	CARBON RES.	1/6W(F) 270			
TH201	THERMISTOR	TD5-210DH			
VC201	TRIMMER	DTM 20PF			
	VCO STUD	4A10-1267			
	PCB	06VCUDR216			
	PCB MAT	4A10-1273			
	RUBBER MAT	4A10-1041			
	VCO INTERIOR MAT	4A10-1123			
	VCO UNIT CASE	4A10-1095			
	VCO UNIT FRAME	4A10-1038			
	VCO UNIT COVER	4A10-1193			
	SEMS SCREW	SE-2.6x5			
MODEL:KG106 UHF			UNIT:TX PA		
REF.NO.	PART NAME	PART NO.	REF.NO.	PART NAME	PART NO.
C601,3,5	CERAMIC CAP.		C601,3,5	CERAMIC CAP.	B 470PF
C602,03,06	ELECTROLYTIC CAP.		C602,03,06	ELECTROLYTIC CAP.	KMA 25V/10UF
C607	ELECTROLYTIC CAP.		C607	ELECTROLYTIC CAP.	KMA 25V/33UF
C609A	MICA CHIP CAP.		C609A	MICA CHIP CAP.	UC342H 220PF
C610	MICA CHIP CAP.		C610	MICA CHIP CAP.	UC232H 3PP
C613,14	MICA CHIP CAP.		C613,14	MICA CHIP CAP.	UC232H 33PF
C615,16	MICA CHIP CAP.		C615,16	MICA CHIP CAP.	UC342H 43PF
C617-19	MICA CHIP CAP.		C617-19	MICA CHIP CAP.	UC232H 18PF
C621	FILM CAP.		C621	FILM CAP.	A7Z 0.022UF
C622,37,39	ELECTROLYTIC CAP.		C622,37,39	ELECTROLYTIC CAP.	KMA 25V/10UF
C623	THROUGH CAP.		C623	THROUGH CAP.	1HB34Y 1000PF
C626-29,38	CERAMIC CAP.		C626-29,38	CERAMIC CAP.	B 470PF
C630,31,33,34	MICA CHIP CAP.		C630,31,33,34	MICA CHIP CAP.	UC232H 10PF
C632,35	MICA CHIP CAP.		C632,35	MICA CHIP CAP.	UC232H 5PF
C640,43,49-51	CERAMIC CAP.		C640,43,49-51	CERAMIC CAP.	B 1000PF
C641	FILM CAP.		C641	FILM CAP.	A7Z 0.01UF
C642	MONOLITHIC CERAMIC CAP.		C642	MONOLITHIC CERAMIC CAP.	RPEI21C 0.01UF
C644-16,48	CERAMIC CAP.		C644-16,48	CERAMIC CAP.	B 470PF
C647	MONOLITHIC CERAMIC CAP.		C647	MONOLITHIC CERAMIC CAP.	RPEI21C 1000PF
CN302S	3-PIN ASSY		CN302S	3-PIN ASSY	06-302S
CN3P	COAXIAL CABLE		CN3P	COAXIAL CABLE	106-TX-1SD
CN7P	COAXIAL PLUG		CN7P	COAXIAL PLUG	SEM-R-PC
CN9S	D.C. WIRE		CN9S	D.C. WIRE	06-9S
C406	CHIP CAP.	GR40 RH 4PF	D601,04	DIODE	1SS177
C407	CHIP CAP.	GR40 RH 11PF	D602	DIODE	1SS237
C408	CHIP CAP.	GR40 RH 1.5PF	D603	ZENER DIODE	05ZS.6Y
C409	CHIP CAP.	GR40 RH 18PF	EM601	NOISE ELIMINAT	BNP-002
C410	WEDGE CAP.	SUW35A 1000PF	FVR601	SEMI FIXED RES.	CT-6P 2K
C411	CERAMIC CAP.	RH 2PF	IC601	POWER MODULE	M57704H
C415-17,19,28	CERAMIC CAP.	B 470PF	IC602	IC	NJM4556D
C418,22,23	TANTALUM CAP.	DN 10V/4.7UF	L601-3,10,14,15	LEAD CHOKE	10M(LN0019)
C420,21	ELECTROLIC CAP.	KMA 16V/47UF	L604	COIL	4A-S164
C424	CERAMIC CAP.	B 1000PF	L605	COIL	4A-S163
C425	TANTALUM CAP.	DN 10V/47UF	L606,08	LEAD CHOKE	20M (LN0010)
C426	MONOLITHIC CERAMIC CAP.	PE121C 0.022UF	L607	LEAD CHOKE	15M (LN0009)
C427	TANTALUM CAP.	DN 35V/1UF	L610	COIL	4A-S342
C429	TANTALUM CAP.	DN 35V/0.47UF	L611,13	COIL	4A-S158
C430	CERAMIC CAP.	CH 3PF	L612	COIL	4A-S159
CN305P	7-PIN PLUG	SB-07P-HVQ-B	PS601	POSISTOR	PTH59ED471TS
CN306P	2-PIN PLUG	SB-02P-HVQ-B	Q601	TRANSISTOR	2SC3102
D401	VARICAP DIODE	IT32	Q602	TRANSISTOR	2SB1019B
D402	DIODE	1SS227	Q603	TRANSISTOR	2SA950
D403,05	DIODE	ISS177	Q604	TRANSISTOR	2SC2120Y
D404	ZENER DIODE	05ZS.6Y	Q605	TRANSISTOR	2SC2458LY
IC401	IC	UPC1651	R601	CARBON RES.	1/6W(F) 470
L401	MICRO INDUCTOR	LA03NA 1UH	R602	CARBON RES.	1/4W(F) 150
L402	CHOKE COIL	4A-S212	R606	CARBON RES.	1/6W(F) 82
L403	MICRO INDUCTOR	LA03NA 0.47UH	R607,08	CARBON RES.	1/6W(F) 4.7K
L404	COIL	4A-S210	R609	CARBON RES.	1/4W(F) 47
L405	COIL	4A-S166	R610,13,18,19	CARBON RES.	1/6W(F) 1K
L406	MICRO INDUCTOR	LA04NA 10UH	R611,14	CARBON RES.	1/6W(F) 2.2K
Q401	FET	SST310	R612	CARBON RES.	1/6W(F) R100K
Q402	TRANSISTOR	2SC2753Y	R615,17	CARBON RES.	1/6W(F) 220
Q403,05	TRANSISTOR	2SA1048LY			

REF.NO.	PART NAME	PART NO.	REF. NO.	PART NAME	PART NO.
R616	CARBON RES.	1/6W(F) 100		HEXAGONAL BOLT	5x16
R620	CARBON RES.	1/6W(F) 47K			
R621	CARBON RES.	1/6W(F) 10K			
R622	CARBON RES.	1/6W(F) 820			
VC601,04	TRIMMER	TTC7-10D 10PF			
VC602,03	TRIMMER	TC809-2/18PF			
	WIRE LEAD	0.2sq-135 RED			
	LPF CASE	4A10-0994			
	LPF COVER	4A10-0995			
	PCB	06PAU321			
MODEL:KG106 UHF		UNIT:TERMINAL UNIT			
REF.NO.	PART NAME	PART NO.	REF.NO.	PART NAME	PART NO.
BL1	BALISTER	ENB220	C13	CAP, 0.1 UF 50V 10%	CM1
C1	CERAMIC CAP.	B 1000PF	C18	CAP, 22 PF 50V 10%	CM220
C2	ELECTROLYTIC CAP.	SME 25V/470UF	C6,C11	CAP, 10 UF 25V 10% TANT.	CT106
C3	ELECTROLYTIC CAP.	SME 25V/1000UF	C7	CAP, 1800 PF 50V 10%	CM182
CH1	CHOKE TRANSISTOR	CH-105	C12,C14-C17	CAP, 0.1 UF 50V 10%	CM1
CN101S	8-PIN ASSY	06-101S			
CN102S	12-PIN ASSY	06-102S			
CN301S	8-PIN ASSY	06-301S			
CN303S	7-PIN ASSY	06-303S			
CN8P	D.C. CONNECTOR	SRGN2A-13-3P			
CN9P	2-PIN ASSY	06-9P			
CN10S	37-PIN D-SUB(L)	XMB2-3731			
D1	DIODE	20DL2C	R3,R9,R21,R27	ZENER DIODE 6.2V 0.5W 5%	D5234B
D2	DIODE	DS135D	R4,R13,R19,R23	CONNECTOR, 6-PIN RJ-11C	CON52
J1	JUMPER PLUG	DSP02-002-431G	R5,R6,R10,R12	BASE PIN ASSY, 2 COND.	CON53
J2-J4	JUMPER PLUG	DSP03-003-432G	R7	INDUCTOR, 10 UH 10%	CHOKE-2
Q1	TRANSISTOR	2SC2120Y	R8	MICROPHONE ELEMENT	MICEL
Q2	TRANSISTOR	2SC2458LY			
R1,R4	CARBON RES.	1/6W(F) 4.7K	R11,R14,R15	SOCKET, 2 COND.	CONN5
R2	CARBON RES.	1/6W(F) 10K	R16,R17	SOCKET, 2COND.	CONN55
R3	CARBON RES.	1/6W(F) 1K	R18,R22,R25-R37	TRANSISTOR, NPN SILICON SWITCH.	Q2222
RA1	RES. ARRAY	RGLN8X-103X	R24,R44	RES., 33K OHM 1/8W 5%	RC333
RJ1	RELAY	MR301-12S	R25,R30	RES., 100 OHM 1/8W 5%	RC101
	D-SUB STUD	XMB2-0013	R28,R43	RES., 1M OHM 1/8W 5%	RC1M
	D-SUB COVER	XMB2-3701	R29,R31-R33	RES., 10K OHM 1/8W 5%	RC10K
	JUMPER SOCKET	DSP01-002-430G	R34,R39	RES., 100K OHM 1/8W 5%	RC104
	PCB	06PST31Z	R38	RES., 47K OHM 1/8W 5%	RC473
	PCB	06T-2	R42	RES., 10K OHM 1/8W 5%	RC10K
MODEL:KG106 UHF		UNIT:CHASSIS			
REF.NO.	PART NAME	PART NO.			
CN10P	D-SUB PLUG	F-37P-K117	S2	SWITCH, SLIDE DPDT	SW45L
CN1P	ANT. CONNECTOR	106-ANT-1.5D	S4	SWITCH, 10 POS. SPST	SWD10
CN5S	COAXIAL WIRE	106-RX-1.5D	SP1	SPEAKER, 2" DYNAMIC 80HM 0.5W	SPKR01
CN8P	BATT. CONNECTOR	SRGN6A-13-3S	U1	MICROCOMP., HCmos (MASK ROM)	SMU68HC05
CN8S	D.C. POWER CORD	06-9S	U2	EPROM, SERIAL 256X8	U2402
	CHASSIS	IA11-0015	U3	REGULATOR, 5V 100 MA	U78L05
	PA UNIT HEAT SINK	2A10-0119	U4	QUAD OP. AMP.	UC274
	TOP COVER	2A10-0120 (T)	U5	AUDIO AMP, 0.5W DIP-8	U386
	BOTTOM COVER	2A10-0120 (B)	U6,U8,U9	QUAD NAND GATE, HS CMOS	U74HC00
	BRACKET LOCKER	4A10-1262	U7	HEX INVERTER, OPEN DR. HS CMOS	U74HC05
	KEY & LOCK	VMZ-C (SET)	Y1	CRYSTAL, 3.58 MHZ HC-18/U	XTAL3
	PA COVER	4A10-1280		PLASTIC CASE, HANDSET	HANDSET
	PA STUD	4A10-1281		PTT BUTTON	
	PA SPACER	4A10-1075		KEYPAD ASSEMBLY W/RIBBON CAB.	LABEL055
	D-SUB COVER	F-PHGR-4		LABEL-LED PANEL (CES)	
	FUSE	FU-12.5A			
	MOUNT BRACKET	3A10-0319		SCREW, PHIL. 2.6 x 8 mm	SCREW12
	BRACKET ANGLE	4A10-1264		SCREW, PHIL. 2.3 x 8 mm	SCREW11
	BOLT SPACER	4A10-1263		SCREW, PHIL. 2-56 x 1/4"	SCREW14
	BOTTOM COVER SEAL	4A10-1291		OWNER'S MANUAL	01100711
	RUBBER SEAT	4A10-1279		TEL. NO. LABEL	LABEL032
	RX UNIT SEAL	4A10-1295			
	TX UNIT SEAL	4A10-1296		FUSEHOLDER W/ 1 AMP FUSE	FHOLD2
	CAP BOLT	CAP-4 x 6		COILED CORD ASSY. W/6-PIN PLUGS	CRDHDS1
	CAP BOLT	CAP-4 x 75		SERVICE SHOP PROG. INST.	04100711
				PTT PCB	710
				HANDSET (MAIN) PCB	711
MODEL:HANDSET		UNIT:BASE UNIT			
REF.NO.	PART NAME	PART NO.			
PA	CAP BOLT	CAP-4 x 85			
RX,TX,ANT,BATT,PA	SEMS SCREW	SE-2.6 x 8			
TERM	SEMS SCREW	SE-3 x 8			
PA COVER	SEMS SCREW	SE-3 x 12			
	OVAL SCREW	OV-2.6 x 5			
DUPLEXER	BIND SCREW	BD-3 x 6	C301-C306,C308	CAP, 0.1 UF 50V 10%	CM1
CHA-PA	FLAT SCREW	FT-3 x 8	C307	CAP, 220 UF 25V ELEC.	CE221
	WRENCH	4PAI	C309	CAP, 4.7 UF 25V NP ELEC.	CE4.7NP
			CR301,CR303	ZENER DIODE 18V IW 5%	D4746
			CR304	ZENER DIODE 18V IW 5%	D4747

REF.NO.	PART NAME	PART NO.
CR302	DIODE SWITCHING	D914
J301	CONNECTOR, 6-PIN (MODULAR)	CONS2
J303	BASE PIN ASSY, 8 COND.	CON72
K301	RELAY, DPDT 12V 2A SEALED	RELAY1
L301	INDUCTOR, 10 UH 10%	CHOKE-2
Q301,Q302	TRANS., NPN SILICON	Q2222
Q303	TRANS., MOSFET N-CHAN.	QVN10
R301,R312	RES., 51K OHM 1/8W 5% CF	RC513
R302,R304	RES., 10K OHM 1/8W 5%	RC10K
R303,R305,R309,R317	RES., 10M OHM 1/8W 5% CF	RC10M
R306-R308,R310	RES., 10K OHM 1/8W 5%	RC10K
R311,R313-R315,R325	RES., 10K OHM 1/8W 5%	RC10K
R316,R319	RES., 100K OHM 1/8W 5% CF RC104	
R318	RES., 1.5K OHM 1/8W 5% CF	RC152
R320	RES., 2.2K OHM 1/8W 5% CF	RC222
R321-R324	RES., 100 OHM 1/8W 5% CF	RC101
S301	HOOK SWITCH	
S302	SWITCH, SLIDE SPST 8 POS. DIP	SWD8
U301	QUAD COMPAR., BIPOAR	U339
U302	REGULATOR, 5V 100 MA	U78L05
U303	QUAD 2-INP. LS NAND	U74LS00
U304	QUAD 2-INP. LS NOR	U74LS02
	SCREW, PHIL.	SCREW17
	SCREW, PHIL.	SCREW13
	PLASTIC CASE, BASE UNIT	
	HOOK SWITCH LEVER	
	RETAINER	
	BUTTON	
	SPRING	
	CABLE CLAMP	CABLECLAMP
	WASHER	WASHER04
	SCREW, PHIL. 2.5 x 8mm	SCREW11
	BASE UNIT PCB	707